KitchenAid® COOKTOP PARTS

30" FREE STANDING
ELECTRIC OVEN
CONVECTION

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00

(Black) (S.Steel) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Literaturre Parts
	9757446	Installation Instructiions
	9757451	Use & Care Guide
	9757456	Use & Care Guide (French)
	9757662	Tech Sheet
	9757680	Anti−Tip Instruct.
	3191638	Safe Cooking Tips
2	8523739	Light, Indicator (Hot Surface)
3	4454023	Bracket, Mounting
	3179776	Screw
4		Cooktop
	9759748BL	Black
	9759748SS	S.Steel
	9759748WW	White
	9759748BB	Biscuit
	9756450	Gasket
5	4453764	Clip, Ceran (2)
	3179776	Screw

Illus. No.	Part No.	DESCRIPTION
6		Trim−CkTop, SI
	9756700BL	Black LH
	9756700SS	S.Steel LH
	9756700WH	White LH
	9756700BT	Biscuit LH
	9756701BL	Black RH
	9756701SS	S.Steel RH
	9756701WH	White RH
	9756701BT	Biscuit RH
	3179776	Screw
7		Switch, Infinite
	9759781	RF
	9759782	LF, RR, LR
8	9756929	Light, Indicator
9		Support
	9757686	L.Hand
	9757687	R.Hand
10	9756821	Support, Wiring
	4449809	Screw (2)
12		Element, Surface
	8203525	1800/1000W
	8523696	1800W RR
	9756697	2500/1000W (2)

Illus. No.	Part No.	DESCRIPTION
13	9757800	Bracket, Front Support
	3179776	Screw (4)
14	4454019	Cover, Backsplash Rear
15		Backsplash
	9759895BL	Black
	9759895WH	White
	9759895BT	Biscuit
	9759886SS	S.Steel
		Gasket
	9757767BL	Black
	9757767GY	Gray
16	9751984	Bi−Metal
	3196160	Screw (2)
17	9758799	Bracket, Ind. Lamp
	3196160	Screw (2)
19	3191791	Spring, Locator
20	9759956	Bracket, Rear Sprt
	3179776	Screw (4)
21	9756813	Rail, Element (2)
	3179776	Screw (4)
22	3179776	Screw
23	9759626	Cover, Cktp Rear
	3179776	Screw (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00
(Black) (S.Steel) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	4453840BL	Black
	4453840SS	S.Steel
	4453840WH	White
	4453840BT	Biscuit
2		Membrane Switch
	9756595BL	Black
	9756595SS	S.Steel
	9756595WH	White
	9756595BT	Biscuit
	3400832	Screw

Illus. No.	Part No.	DESCRIPTION
3	9759565	Control, Interface
	9780271	Screw
4	9757119	Bracket, Console
	3179776	Screw (3)
5	3196068	Lens, Ind. (2)
8		Endcap
	4453880BL	Black LH
	4453880CM	S.Steel LH
	4453880WH	White LH
	4453880BT	Biscuit LH
	4453884BL	Black RH
	4453884CM	S.Steel RH
	4453884WH	White RH
	4453884BT	Biscuit RH
	3196172	Screw

Illus. No.	Part No.	DESCRIPTION
9		Knob
	9756943	Black
	9756941	White
	9756942	Biscuit
10		Nameplate
	9757730BL	Black
	9757730WH	White
	9757730BT	Biscuit
	4453107	Nut

OVEN PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00

(Black) (S.Steel) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00
(Black) (S.Steel) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)
	9756619BL	Black
	9756619SS	S.Steel
	9756619WH	White
	9756619BT	Biscuit (Left Hand)
	9756620BL	Black
	9756620SS	S.Steel
	9756620WH	White
	9756620BT	Biscuit
	3400832	Screw
3		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	9757717	Insulation, Bottom Vent
7	4455865	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	3196176	Screw
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
13	9757732	Shield, Heat
	4449743	Screw (4)
14	4455612	Frame, Front
	4449040	Screw
	4450118	Nut
15	4455382	Gasket, Door
16	4453951	Deflector, Vent Bottom
17	4452152	Bracket, Mounting
18	9757685	Guide, Side Panel
19	4451478	Support, Insulation
	4449809	Screw
20		Body, Side
	9781907PB	Black
	9781907PW	White
	9781907PC	Biscuit
22	8302474	Latch, Motorized
	4449154	Screw
23	341196	Thermostat SPST (205)
25	4455641	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	9759761	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
	4449154	Screw
30	9756454	Bracket, GOC
	4449809	Screw
31	9756452	Slide. GOC
	3179776	Screw
32	9759561	Central, Appliance
37	4452223	Thermostat (TOD) Manager
	3179776	Screw (Temp.) SPST
43	9759713	Base, Chassis
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
54		Vent, Bottom Upper
	9756481BL	Black
	9756481SS	S.Steel
	9756481WH	White
	9756481BT	Biscuit
55		Trim, Btm Vent
	9756485BL	Black
	9756485SS	S.Steel
	9756485WH	White
	9756485BT	Biscuit

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

9756817	Insulation, Wrap
9756470	Insulation, Back

DOOR AND DRAWER PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00

(Black) (S.Steel) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00

(Black) (S.Steel) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
5		Glass, Door Front
	9757102BL	Black
	9757102SS	S.Steel
	9757102WH	White
	9757102BT	Biscuit
8		Handle, Door
	9756833BL	Black
	9756833OG	S.Steel
	9756833WH	White
	9756833BT	Biscuit
9	8302094	Bracket, Central
10		Hinge, Door
	8300579	Orange
	8300580	Orange
	4449743	Screw
11	312701	Foot, Rear
12	8302092	Bracket, Side
13	8274149	Sensor
	3196537	Screw
14	8054056	Element, Warming
	4449809	Screw
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	4449263	Glass, Inner (2)
18	4451722	Insulation, Door
19	4455618	Liner, Door
20	9757805	Drawer Assy
21	3196037	Foot, Front
	4449743	Screw
22	9757796	Panel, Drawer
23	9759743	Retainer, Door
24		Front, Drawer
	4453799BL	Black
	4453799SS	S.Steel
	4453799WH	White
	4453799BT	Biscuit
25		Bracket, Handle
	8301837	R.Hand
	8301838	L.Hand
	8533988	Screw
26		Handle, Drawer
	9756952BL	Black
	9756952CM	S.Steel
	9756952WH	White
	9756952BT	Biscuit
32		Guide, Roller
	4453719	R.Hand
	4453718	L.Hand
33	9757707	Shield, Heat Top

INTERNAL OVEN PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00

(Black) (S.Steel) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	4451583	Motor, Convection
2	8301514	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
	4449154	Screw
8	4448948	Probe, Meat
9	4452157	Element, Convect.
	4449154	Screw
10	9756690	Cover, Fan
	4449154	Screw
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451355	Jack, Meat Probe
14	4448882	Lock Washer
15	4448881	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00

(Black) (S.Steel) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
	4449040	Screw, 8−18 x 3/8
2	4455178	Elbow, Vent Top
3	8300223	Blower
	4455352	Bracket
	4449809	Screw (4)
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
8	9760003	Box, Terminal
	4449809	Screw (3)
11	4449868	Block, Terminal
	3400080	Screw
12	9759876	Cover, Term Box
	3196160	Screw (2)
13	9757118BL	Vent, (Control Panel)
	4450038	Screw
14	9757829	Bracket, Transfrmr
	4449809	Screw
15	9756551	Transformer
	4449809	Screw

OPTIONAL PARTS (NOT INCLUDED)

For Models: YKERA807PB00, YKERA807PS00, YKERA807PP00, YKERA807PC00
(Black) (S.Steel) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
	261869	Cord Brown
	72032	Black
PAINT, SPRAY		
	350930	White
	261900	Citrine White
	830864	Black
ADHESIVE		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
SPLICING WIRES−−25FT. LENGTH		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
WIRING HARNESS PARTS		
	9759791	Harness, Wire (Main)
	9756554	Harness, Wire Comm.
	9759793	Harness, Wire (Switch, Elec)
	9759603	Harness, Main Smart, Knob
	9759604	Harness, Wire (Left)
	9759605	Harness, Wire (Right)
	9759855	Harness, APSSC Smart Knob
	9759922	Conduit
	313660	Clip, Ground Wire
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4452222	Spacer, Harness
	3400015	Screw, Ground
Miscellaneous		
	814381	Hinge Pin Kit
	4448950	Screw, Install (4)
	9782676	Anit−Tip Assy